

EMISSION CONTROL SYSTEMS

CONTENTS

	page		page
EVAPORATIVE EMISSION CONTROLS	2	EXHAUST EMISSION CONTROLS	8

GENERAL INFORMATION

Throughout this group, references may be made to a particular vehicle by letter or number designation. The Introduction Section at the front of this manual contains a chart showing the breakdown of the designations.

EMISSION MAINTENANCE REMINDER (EMR) SYSTEM

Some systems and components require periodic maintenance. For example, the PCV valve, EGR system, the heated oxygen sensor, and some vacuum operated components require periodic service.

The engine controller operates the Emissions Maintenance Reminder (EMR) system. Every 8 miles, the engine controller records vehicle mileage and stores it into memory. When storing the mileage into memory, the engine controller checks for the 96,000 km (60,000 mile), 132,000 km (82,500 mile) and 192,000 km (120,000 mile) intervals. When the current mileage matches a specified interval, the controller turns the EMR light on.

Replace the following parts at the indicated mileage, or when the EMR light remains on continuously with the key in the **on** position, whichever occurs first.

- 96,000 km (60,000 miles):
 - (a) Replace EGR Valve.

- (b) Replace EGR Tube (if equipped).
 - (c) Clean EGR passage.
 - (d) Replace PCV Valve.
- 132,000 km (82,500 miles):
- (a) Replace Oxygen Sensor.
- 192,000 km (120,000 miles):
- (a) Replace EGR Valve.
 - (b) Replace EGR Tube (if equipped).
 - (c) Clean EGR passage.
 - (d) Replace PCV Valve.

After performing the required maintenance, the EMR system must be reset to turn off the light.

Failure to perform the required maintenance and only reset the EMR light may be a violation of federal law. Reset the EMR light only after performing the required maintenance.

RESETTING EMR LAMP

- (1) Connect DRB II tool to the diagnostic connector.
- (2) Turn the ignition switch to the run position, access **Select Systems** on the DRB II.
- (3) Select the applicable engine.
- (4) Select with or without air conditioning.
- (5) Select **Fuel and Ignition**.
- (6) Select **Adjustments**
- (7) Select **Reset EMR Light**.
- (8) Reset the EMR Light.



CALIFORNIA VEHICLE CONTROL INFORMATION LABEL—TYPICAL

TWC, H02S, SMP1	IMPORTANT VEHICLE INFORMATION							
	THIS VEHICLE CONFORMS TO U.S. EPA AND STATE OF CALIFORNIA REGULATIONS APPLICABLE TO 1992 MODEL YEAR NEW LIGHT-DUTY TRUCKS PROVIDED THAT THIS VEHICLE IS ONLY INTRODUCED INTO COMMERCE FOR SALE IN THE STATE OF CALIFORNIA							
CATALYST	*BASIC IGNITION TIMING AND IDLE FUEL/AIR MIXTURE HAVE BEEN PRESET AT THE FACTORY. SEE THE SERVICE MANUAL FOR PROPER PROCEDURES AND OTHER ADDITIONAL INFORMATION.	3.0 LITER NCR3.0T5FFV8 NCRTC						
	*ADJUSTMENTS MADE BY OTHER THAN APPROVED SERVICE MANUAL PROCEDURES MAY VIOLATE FEDERAL AND STATE LAWS. CAUTION: APPLY PARKING BRAKE WHEN SERVICING VEHICLE	SPARK PLUGS 1.1mm GAP RN11YC4						
5283448		<table border="1"> <tr> <td>IDLE TIMING BTC</td> <td>AUTO 12°</td> </tr> <tr> <td colspan="2">NO OTHER ADJUSTMENTS NEEDED</td> </tr> <tr> <td>RHC/CO/NO_x STDS.</td> <td>39/9.0/0.7</td> </tr> </table>	IDLE TIMING BTC	AUTO 12°	NO OTHER ADJUSTMENTS NEEDED		RHC/CO/NO _x STDS.	39/9.0/0.7
	IDLE TIMING BTC	AUTO 12°						
NO OTHER ADJUSTMENTS NEEDED								
RHC/CO/NO _x STDS.	39/9.0/0.7							
CHRYSLER CORPORATION	<p style="text-align: right;">--- OPTIONAL VACUUM OPERATED ACCESSORIES</p>							

9225-2

CANADA VEHICLE EMISSION CONTROL INFORMATION LABEL—TYPICAL


4669438	VEHICLE EMISSION CONTROL INFORMATION													
	THIS VEHICLE WAS BUILT FOR SALE IN CANADA AND WAS DESIGNED TO MEET THE EMISSION REQUIREMENTS OF THE CANADA MOTOR VEHICLE SAFETY ACT. IT WAS NOT DESIGNED TO COMPLY WITH THE REQUIREMENTS OF OTHER COUNTRIES.													
CHRYSLER CANADA	*BASIC IGNITION TIMING AND FUEL INJECTION MIXTURE HAVE BEEN PRESET AT THE FACTORY. ADJUSTMENTS SHOULD NOT BE MADE DURING ROUTINE SERVICE. CAUTION: APPLY PARKING BRAKE WHEN SERVICING VEHICLE	<table border="1"> <tr> <td>2.5 LITER</td> <td colspan="2">SPARK PLUGS 0.9mm GAP RN12YC</td> </tr> <tr> <td>IDLE TIMING BTC</td> <td>MAN 12°</td> <td>AUTO 12°</td> </tr> <tr> <td colspan="3">FAMILY NO_x EMISSION LIMIT 1.1</td> </tr> </table>	2.5 LITER	SPARK PLUGS 0.9mm GAP RN12YC		IDLE TIMING BTC	MAN 12°	AUTO 12°	FAMILY NO _x EMISSION LIMIT 1.1					
	2.5 LITER	SPARK PLUGS 0.9mm GAP RN12YC												
IDLE TIMING BTC	MAN 12°	AUTO 12°												
FAMILY NO _x EMISSION LIMIT 1.1														
	RENSEIGNEMENTS RELATIFS AU SYSTÈME ANTIPOLLUTION													
	LE PRÉSENT VÉHICULE A ÉTÉ FABRIQUÉ POUR ÊTRE VENDU AU CANADA ET IL A ÉTÉ CONÇU DE MANIÈRE À SE CONFORMER AUX NORMES ANTIPOLLUTION DE LA LOI SUR LA SÉCURITÉ DES VÉHICULES AUTOMOBILES DU CANADA. IL N'EST PAS DESTINÉ À SE CONFORMER AUX NORMES D'AUTRES PAYS.													
	*LE CALAGE DE L'ALLUMAGE INITIAL ET LE MÉLANGE D'INJECTION D'ESSENCE ONT ÉTÉ PRÉRÉGLÉS À L'USINE. N'EFFECTUEZ AUCUN RÉGLAGE LORS DE TRAVAUX D'ENTRETIEN RÉGULIERS. AVERTISSEMENT: SERREZ LE FREN DE STATIONNEMENT POUR FAIRE L'ENTRETIEN OU LA RÉPARATION DU VÉHICULE.	<table border="1"> <tr> <td>2.5 LITER</td> <td colspan="2">SPARK PLUGS 0.9mm GAP RN12YC</td> </tr> <tr> <td>RÉGLAGE DU RALENTI</td> <td>MAN 12°</td> <td>AUTO 12°</td> </tr> <tr> <td colspan="3">DISTRIBUTION AV P.H.</td> </tr> <tr> <td colspan="3">LIMITE DES GAZ D'ÉCHAPPEMENT NO_x DU GROUPE MOTEUR 1.1</td> </tr> </table>	2.5 LITER	SPARK PLUGS 0.9mm GAP RN12YC		RÉGLAGE DU RALENTI	MAN 12°	AUTO 12°	DISTRIBUTION AV P.H.			LIMITE DES GAZ D'ÉCHAPPEMENT NO _x DU GROUPE MOTEUR 1.1		
2.5 LITER	SPARK PLUGS 0.9mm GAP RN12YC													
RÉGLAGE DU RALENTI	MAN 12°	AUTO 12°												
DISTRIBUTION AV P.H.														
LIMITE DES GAZ D'ÉCHAPPEMENT NO _x DU GROUPE MOTEUR 1.1														
	<p style="text-align: right;">--- OPTIONAL VACUUM OPERATED ACCESSORIES</p>													

9225-1

VACUUM SCHEMATICS


If any difference exists between the label and the schematics in the Service Manual, refer to the label.

ENGINE VACUUM SCHEMATIC—2.5L ENGINE



9225-4

ENGINE VACUUM SCHEMATIC—3.0L ENGINE



9225-5




Fig. 2 Evaporative Canister

the solenoid, vacuum flows to the canister purge valve. Intake manifold vacuum purges fuel vapors through the throttle body. The engine controller also energizes the purge solenoid during certain idle conditions to update the fuel delivery calibration. **Refer to On Board Diagnostics in the General Diagnosis section of Group 14 for test procedures.**




Fig. 3 Canister Purge Solenoid

PRESSURE-VACUUM FILLER CAP

CAUTION: Remove the fuel filler cap to relieve fuel tank pressure. The cap must be removed prior to disconnecting any fuel system component or servicing the fuel tank.

A pressure-vacuum relief cap seals the fuel tank (Fig. 4). Tightening the cap on the fuel filler tube forms a seal between them. The relief valves in the cap are a safety feature. They prevent possible excessive pressure or vacuum in the tank. Excessive fuel tank pressure could be caused by a malfunction in the system or damage to the vent lines.

The seal between the cap and filler tube breaks when the cap is removed. Removing the cap breaks the seal and relieves fuel tank pressure.

If the filler cap needs replacement, only use a similar unit.




Fig. 4 Pressure Vacuum Filler Cap

POSITIVE CRANKCASE VENTILATION (PCV) SYSTEMS

Intake manifold vacuum removes crankcase vapors and piston blow-by from the engine. The emissions pass through the PCV valve into the intake manifold where they become part of the calibrated air-fuel mixture. They are burned and expelled with the exhaust gases. The air cleaner supplies make up air when the engine does not have enough vapor or blow-by gases. In this system, fresh air does not enter the crankcase (Figs. 5, 6, 7, 8, 9).




Fig. 5 PCV Valve 2.5L Engine

PCV VALVE TEST

WARNING: APPLY PARKING BRAKE AND/OR BLOCK WHEELS BEFORE PERFORMING ANY TEST OR ADJUSTMENT WITH THE ENGINE OPERATING.

With the engine idling, remove the PCV valve from its attaching point. If the valve is operating properly, a hissing noise will be heard and a strong vacuum felt when placing a finger over the valve inlet (Fig. 10). With the engine off, the shake the valve. The valve should rattle when shaken. Replace




Fig. 6 PCV Valve 3.0L Engine




Fig. 9 Fresh Air Hose—3.3L Engine PCV System




Fig. 7 Fresh Air Hose—3.0L Engine PCV System




Fig. 8 PCV Valve 3.3L Engine




Fig. 10 Typical PCV Test

CRANKCASE VENT FILTER

All engines have a crankcase vent filter. The filter cleans outside air before it enters the PCV system. On 2.5L engines, the filter mounts to the upper shell assembly of the air cleaner. On 3.0L engines, it attaches to the inside of the filter element box under the filter element. On the 3.3L engines, the mounts to the bottom of the filter element box. (Refer to Group 0 for mileage intervals and service procedures.)

the valve if it does not operate properly. Do not attempt to clean the PCV valve.

EXHAUST EMISSION CONTROLS

INDEX

	page		page
EGR System Service	13	Heated Inlet Air System	8
Exhaust Gas Recirculation (EGR) System	10	Heated Oxygen Sensor (O ₂ Sensor)	9

HEATED INLET AIR SYSTEM

The 3.0L and 3.3L engines do not have a heated inlet air system.

The 2.5L engine air cleaner has a heated air assembly (Fig. 1). When ambient temperatures are low, the assembly warms the air before it enters the throttle body. The heated air assembly reduces hydrocarbon emissions, improves engine warm-up characteristics and minimizes icing.




Fig. 1 Heated Air Inlet System

The heated air assembly contains a vacuum operated blend door. The blend door opens to either heated air from a stove on the exhaust manifold or ambient air (outside air). A vacuum diaphragm operates the door. A spring opposes the vacuum diaphragm. A temperature sensor controls the vacuum diaphragm (Fig. 2). Adjustment of inlet air temperature occurs only at road load throttle positions or when the intake manifold vacuum exceeds the vacuum diaphragm spring rate.

Air flows through the outside air inlet when ambient air temperature is 8°C (15°F) or more above the air temperature sensor control temperature.

When ambient air temperature falls below the control temperature, air flows through both the ambient




Fig. 2 Heated Air Temperature Sensor

and heated circuits. This occurs after the engine has been started and the exhaust manifold starts to give off heat. Colder ambient air cause greater air flow through the heat stove on the exhaust manifold. Warmer ambient air results in greater ambient air flow through the air cleaner snorkel.

HEATED INLET AIR SYSTEM SERVICE

Heated air inlet system malfunctions may affect driveability and vehicle exhaust emissions.

Use the following procedure to determine if the system functions properly.

(1) Inspect the condition of the heat stove to air cleaner flexible connector and all vacuum hoses. Inspect them for proper attachment. Replace as necessary.

(2) With a cold engine and ambient temperature less than 46°C (115°F), the heat control door (valve plate) should be in the **up** or **heat on position**.

(3) With the engine warmed up and running, check the air temperature entering the snorkel or at the sensor. When the air temperature entering the outer end of snorkel is 60°C (140°F) or higher, the door should be in the **down position (heat off)**.

(4) Remove the air cleaner from the engine and allow it to cool down to 46°C (115°F). With 20 inches of vacuum applied to the sensor, the door should be in the **up** or **(heat on position)**. If the door does not rise to the **heat on position**, check the vacuum diaphragm for proper operation.

(5) To test the diaphragm, apply 20 inches of vacuum to the diaphragm with vacuum pump tool number C-4207 or equivalent (Fig. 3). The diaphragm should not bleed down more than 10 inches of vacuum in 5 minutes. The door should not lift off the bottom of the snorkel at less than 2 inches of vacuum. The door should be in the full **up** position with no more than 4 inches of vacuum.

(6) If the vacuum diaphragm does not perform adequately, replace the heated air assembly.




Fig. 3 Testing Vacuum Diaphragm on Heated Air Inlet Systems

(7) If the vacuum diaphragm performs adequately but proper temperature is not maintained, replace the sensor and repeat the temperature checks in steps 2 and 3.

HEATED AIR TEMPERATURE SENSOR SERVICE

REMOVAL

With air cleaner housing removed from vehicle:

(1) Disconnect vacuum hoses from sensor, remove retainer clips (Fig. 4), and discard (new clips are supplied with a new sensor).

(2) Remove sensor with gasket and discard.

INSTALLATION

(1) Position gasket on the sensor. Install sensor (Fig. 5).

(2) While supporting the sensor on outer diameter, install new retainer clips securely. Ensure the gasket compresses to form an air seal. **Do not attempt to adjust the sensor.**

HEATED OXYGEN SENSOR (O₂ SENSOR)

The O₂ sensor threads into the exhaust manifold. It provides an input voltage to the engine controller. The input tells the engine controller the oxygen content of the exhaust gas (Fig. 6, 7 or 8). The engine controller




Fig. 4 Removing Sensor Clips




Fig. 5 Installing Gasket and Sensor




Fig. 6 Oxygen Sensor—2.5L Engine

uses this information to fine tune the air-fuel ratio by adjusting injector pulse width.

The O₂ sensor produces voltages from 0 to 1 volt, depending upon the oxygen content of the exhaust gas in the exhaust manifold. When a large amount of




Fig. 7 Oxygen Sensor—3.0L Engine




Fig. 8 Oxygen Sensor—3.3L Engine

oxygen is present (caused by a lean air-fuel mixture), the sensor produces a low voltage. When there is a lesser amount present (rich air-fuel mixture) the sensor produces a higher voltage. By monitoring the oxygen content and converting it to electrical voltage, the sensor acts as a rich-lean switch.

The oxygen sensor contains a heating element that keeps it at proper operating temperature during all operating modes. Maintaining correct sensor temperature at all times allows the system to enter into closed loop operation sooner and to remain in closed loop operation during periods of extended idle.


In "Closed Loop" operation the engine controller monitors the O₂ sensor input (along with other inputs) and adjusts the injector pulse width accordingly. During "Open Loop" operation the engine controller ignores the O₂ sensor input. The controller adjusts injector pulse width based on preprogrammed (fixed) oxygen sensor input values and the current inputs from other sensors.

REMOVAL

CAUTION: Do not pull on the oxygen sensor wire when disconnecting the electrical connector.

WARNING: THE EXHAUST MANIFOLD MAY BE EXTREMELY HOT. USE CARE WHEN SERVICING THE OXYGEN SENSOR.

- (1) Disconnect oxygen sensor electrical connector.
- (2) Remove sensor using Tool C-4907 (Fig. 9).



9114-106

Fig. 9 Oxygen Sensor Socket

After removing the sensor, the exhaust manifold threads must be cleaned with an 18 mm X 1.5 + 6E tap. If reusing the original sensor, coat the sensor threads with an anti-seize compound such as Loctite 771-64 or equivalent. New sensors have compound on the threads and do not require an additional coating. Tighten the sensor to 27 N•m (20 ft. lbs.) torque.

EXHAUST GAS RECIRCULATION (EGR) SYSTEM

Exhaust Gas Recirculation (EGR) systems may be used on certain California vehicles equipped with a 3.0L engine and an automatic transmission.

The EGR system reduces oxides of nitrogen (NO_x) in engine exhaust and helps prevent spark knock. The system allows a predetermined amount of hot exhaust gas to recirculate and dilute the incoming air/fuel mixture. The diluted air/fuel mixture reduces peak flame temperature during combustion.

The EGR system (Fig. 10) consists of:

- EGR tube (connects a passage in the intake manifold to the exhaust manifold)
- EGR valve
- Electronic EGR Transducer (EET)
- Connecting hoses

The electronic EGR transducer (EET) contains an electrically operated solenoid and a back-pressure transducer (Fig. 11). The engine controller operates the solenoid. The controller determines when to energize the solenoid. Exhaust system back-pressure controls the transducer.




Fig. 10 EGR System—3.0L Engine




Fig. 11 Electric EGR Transducer (EET) Assembly

When the controller energizes the solenoid, vacuum does not reach the transducer. Vacuum flows to the transducer when the controller de-energizes the solenoid.

When exhaust system back-pressure becomes high enough, it fully closes a bleed valve in the transducer. When the controller de-energizes the solenoid and back-pressure closes the transducer bleed valve, vacuum flows through the transducer to operate the EGR valve.

De-energizing the solenoid, but not fully closing the transducer bleed hole (because of by low back-pressure), varies the strength of vacuum applied to the EGR valve. Varying the strength of the vacuum changes the amount of EGR supplied to the engine. This provides the correct amount of exhaust gas recirculation for different operating conditions.

This system does not allow EGR at idle. The EGR systems can operate at all temperatures above 60°F.

EGR SYSTEM ON-BOARD DIAGNOSTICS (CALIFORNIA VEHICLES)

The engine controller performs an on-board diagnos-

tic check of the EGR system on all California vehicles with EGR systems. The diagnostic system uses the Electric EGR Transducer (EET) for the system tests.

The diagnostic check activates only during selected engine/driving conditions. When the conditions are met, the engine controller energizes the transducer solenoid to disable the EGR. The controller checks for a change in the oxygen sensor signal. If the air-fuel mixture goes lean, the engine controller will attempt to enrichen the mixture. The engine controller registers a fault if the EGR system has failed or degraded. After registering a fault, the engine controller turns the **CHECK ENGINE** light on. The **CHECK ENGINE** light indicates the need for immediate service.

If a malfunction is indicated by the **CHECK ENGINE** light and a fault code for the EGR system, check for proper operation of the EGR system. Use the System Test, EGR Gas Flow Test and EGR Diagnosis Chart. If the EGR system tests properly, check the system using the DRB II tester. Refer to On-Board Diagnosis in the General Diagnosis sections of Group 14. Also, refer to the DRB II and the appropriate Powertrain Diagnostics Procedure manual.

EXHAUST GAS RECIRCULATION (EGR) SYSTEM TEST

WARNING: APPLY PARKING BRAKE AND/OR BLOCK WHEELS BEFORE PERFORMING EGR SYSTEM TEST.

A failed or malfunctioning EGR system can cause engine spark knock, sags or hesitation, rough idle, and/or engine stalling. To ensure proper operation of the EGR system, all passages and moving parts must be free of deposits that could cause plugging or sticking. Ensure that the system hoses does not leak. Replace leaking components.

Inspect hose connections between throttle body, intake manifold, EGR solenoid and transducer, and the EGR valve. Replace hardened, cracked, or melted hoses. Repair or replace faulty connectors.

Check the EGR control system and EGR valve with the engine fully warmed up and running (engine coolant temperature over 150°F). With the transmission in neutral and the throttle closed, allow the engine to idle for 70 seconds. Abruptly accelerate the engine to approximately 2000 rpm, but not over 3000 rpm. The EGR valve stem should move when accelerating the engine (the relative position of the groove on the EGR valve stem should change). Repeat the test several times to confirm movement. If the EGR valve stem moves, the control system is operating normally. If the control system is not operating normally, refer to the EGR Diagnosis Chart to determine the cause.

EGR DIAGNOSIS CHART

NOTE: ALL TESTS MUST BE MADE WITH FULLY WARM ENGINE RUNNING CONTINUOUSLY FOR AT LEAST TWO MINUTES.

WARNING: BE SURE TO APPLY PARKING BRAKE AND/OR BLOCK WHEELS BEFORE PERFORMING IDLE CHECK OR ADJUSTMENT, OR ANY ENGINE RUNNING TESTS OR ADJUSTMENTS.

Condition	Possible Cause	Correction
EGR VALVE STEM DOES NOT MOVE ON SYSTEM TEST.	(a) Cracked, leaking, disconnected or plugged hoses.	(a) Verify correct hose connections and leak check and confirm that all hoses are open. If defective hoses are found, replace hose harness. (b) Disconnect hose harness from EGR vacuum transducer and connect auxiliary vacuum supply. Raise engine rpm to 2000 rpm and hold. Apply 10" Hg vacuum while checking valve movement. If no valve movement occurs, replace valve/transducer assy. If valve opens (approx. 3 mm or 1/8" travel), hold supply vacuum to check for diaphragm leakage. Valve should remain open 30 seconds or longer. If leakage occurs, replace valve/transducer assy. If valve is satisfactory, check control system.
EGR VALVE STEM DOES NOT MOVE ON SYSTEM TEST. OPERATES NORMALLY ON EXTERNAL VACUUM SOURCE.	(a) Defective control system— plugged passages. (b) Defective control system— solenoid or solenoid control circuit.	(a) Remove throttle body and inspect port (slot type) in throttle bore and associated passage in throttle body. Use suitable solvent to remove deposits and check for flow with light air pressure. Normal operation should be restored to EGR system. (b) Refer to Group 14, General Diagnosis "On Board Diagnostics" to check solenoid.
ENGINE WILL NOT IDLE. DIES OUT ON RETURN TO IDLE OR IDLE IS VERY ROUGH OR SLOW.	(a) High EGR valve leakage in closed position. (b) EGR tube to intake manifold leak. (c) Solenoid or control signal to solenoid failure.	(a) If removal of vacuum hose from EGR valve does not correct rough idle, (a1) Turn engine off. Remove the air cleaner exposing the inlet to the throttle body. (a2) Disconnect the backpressure hose from the EGR valve. (a3) Using a nozzle with a rubber grommet connection, direct compressed air (50 to 60 psi) down through the steel backpressure tube on the EGR valve while opening and closing the throttle blade. (a4) If the sound from the compressed air changes distinctly in step a3, the poppet is leaking and air is entering the intake manifold. Replace the EGR valve. (b) Remove tube and visually inspect tube seal on gasket. Tube end should be uniformly indented on gasket with no signs of leak. If signs of exhaust gas leakage are present, replace gaskets and tighten flange nuts to 23 N·m (200 in. lbs.). If an intake plenum leak persists, replace EGR tube and gaskets, following installation instructions. (c) Verify correct hose connections and leak check and confirm that all hoses are open. If defective hoses are found, replace hose harness. (c1) Refer to Group 14, General Diagnosis "On Board Diagnostics" to check solenoid.

NOTE: DO NOT ATTEMPT TO CLEAN BACKPRESSURE EGR VALVE, REPLACE ENTIRE VALVE/TRANSDUCER ASSEMBLY IF NECESSARY.

EGR GAS FLOW TEST

The following procedure should be used to determine if exhaust gas is flowing through the EGR system:

Connect a hand vacuum pump to the EGR valve vacuum motor. With engine running at idle speed, slowly apply vacuum. Engine speed should begin to drop when applied vacuum reaches 2.0 to 3.5 inches. Engine speed may drop quickly or engine may even stall. This indicates that EGR gas is flowing through the system.

If both the EGR Gas Flow Check, System Check and Diagnosis Chart are completed satisfactorily, then the EGR system functions normally.

If engine speed does not drop off when performing the test, remove both the EGR valve and EGR tube and check for plugged passages. Also, check the intake manifold inlet passage. Clean or replace these components for restoration of proper flow.

EGR SYSTEM SERVICE

The EGR valve and Electrical EGR Transducer (EET) are serviced as an assembly.

EGR VALVE REMOVAL

(1) Disconnect vacuum line between the throttle body and the electric EGR transducer (EET). Inspect for damage.

(2) Remove EGR valve mounting bolts.

(3) Remove EGR valve.
(4) Clean gasket surfaces. Discard the old gasket. Check for any signs of leakage or cracked surfaces.

INSTALLATION

(1) Place EGR valve and new gasket on manifold.
(2) Tighten EGR bolts to 22 N•m (200 in. lbs.) torque.
(3) Reconnect vacuum line between the throttle body and electric EGR transducer (EET).

EGR TUBE REMOVAL

(1) Remove EGR tube attaching bolts (4) from intake and exhaust manifolds (Fig. 10)
(2) Remove EGR tube.
(3) Clean intake and exhaust manifold gasket surfaces and EGR tube flange gasket surfaces. Discard old gaskets.
(4) Check for signs of leakage or cracked surfaces on the manifolds and tube. Repair or replace as necessary.

INSTALLATION

(1) Loosely connect the EGR tube and new gaskets with the mounting bolts.
(2) Tighten mounting bolts to 22 N•m (200 in.lbs.) torque.

